Operating instructions





Cooling unit

099-008235-EW501

Observe additional system documents!

24.02.2023

Register now and benefit!

Jetzt Registrieren und Profitieren!

www.ewm-group.com



General instructions

MARNING



Read the operating instructions!

The operating instructions provide an introduction to the safe use of the products.

- Read and observe the operating instructions for all system components, especially the safety instructions and warning notices!
- Observe the accident prevention regulations and any regional regulations!
- The operating instructions must be kept at the location where the machine is operated.
- Safety and warning labels on the machine indicate any possible risks.
 Keep these labels clean and legible at all times.
- The machine has been constructed to state-of-the-art standards in line with any applicable regulations and industrial standards. Only trained personnel may operate, service and repair the machine.
- Technical changes due to further development in machine technology may lead to a differing welding behaviour.

In the event of queries on installation, commissioning, operation or special conditions at the installation site, or on usage, please contact your sales partner or our customer service department on +49 2680 181-0.

A list of authorised sales partners can be found at www.ewm-group.com/en/specialist-dealers.

Liability relating to the operation of this equipment is restricted solely to the function of the equipment. No other form of liability, regardless of type, shall be accepted. This exclusion of liability shall be deemed accepted by the user on commissioning the equipment.

The manufacturer is unable to monitor whether or not these instructions or the conditions and methods are observed during installation, operation, usage and maintenance of the equipment.

An incorrectly performed installation can result in material damage and injure persons as a result. For this reason, we do not accept any responsibility or liability for losses, damages or costs arising from incorrect installation, improper operation or incorrect usage and maintenance or any actions connected to this in any way.

© EWM AG

Dr. Günter-Henle-Strasse 8 56271 Mündersbach Germany Tel.: +49 2680 181-0, Fax: -244 Email: info@ewm-group.com

www.ewm-group.com

The copyright to this document remains the property of the manufacturer.

Copying, including extracts, only permitted with written approval.

The content of this document has been prepared and reviewed with all reasonable care. The information provided is subject to change; errors excepted.

Data security

The user is responsible for backing up data of all changes from the factory setting. The user is liable for erased personal settings. The manufacturer does not assume any liability for this.



1 Contents

1	Conte	ents		3		
2	For y	For your safety				
	2.1	Notes on	n using these operating instructions	4		
	2.2	Explanat	tion of icons	5		
	2.3		structions			
	2.4	Transpor	rt and installation	9		
3	Inten	ded use		11		
	3.1		ons			
		3.1.1	For operation only with the following equipment			
		3.1.2	Warranty			
		3.1.3	Declaration of Conformity			
		3.1.4	Service documents (spare parts and circuit diagrams)	11		
		3.1.5	Part of the complete documentation	12		
4	Mach	ine desc	ription – quick overview	13		
	4.1		ew / rear view			
5	Desid	nn and fu	nction	15		
٠	5.1	•	ly			
	5.2					
	5.3		ing the supply lines			
	5.4		rt and installation			
		5.4.1	Machine cooling			
		5.4.2	Ambient conditions			
	5.5	Welding	torch cooling system	18		
		5.5.1	Functional characteristics	19		
		5.5.2	Permitted torch coolant	19		
		5.5.3	Maximal hose package length			
		5.5.4	Adding coolant	19		
	5.6	Welding	torch connection	20		
6	Maint	tenance,	care and disposal	21		
	6.1	General		21		
	6.2	Cleaning]	21		
		6.2.1	Dirt filter	21		
	6.3	Maintena	ance work, intervals	22		
		6.3.1	Daily maintenance tasks			
		6.3.2	Monthly maintenance tasks			
		6.3.3	Annual test (inspection and testing during operation)			
	6.4	Disposin	g of equipment	23		
7	Recti	fying fau	Its	24		
	7.1	Checklis	t for rectifying faults	24		
	7.2		olant circuit			
	7.3	Fixing the	e pump shaft (coolant circuit)	25		
8	Tech	nical data	a	26		
	8.1	cool 35 l	J31	26		
9	Acce	ssories		27		
-	9.1		torch cooling system			
		9.1.1	Coolant - type blueCool			
		9.1.2	Coolant - type KF			
10	Anne					
. 5	10.1		ng for a dealer			
		2 2 2 3 1 1 1 1	· - · · - · - · · · · · · · · · · · · ·			



2 For your safety

2.1 Notes on using these operating instructions

▲ DANGER

Working or operating procedures which must be closely observed to prevent imminent serious and even fatal injuries.

- · Safety notes include the "DANGER" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol on the edge of the page.

△ WARNING

Working or operating procedures which must be closely observed to prevent serious and even fatal injuries.

- Safety notes include the "WARNING" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol in the page margin.

A CAUTION

Working or operating procedures which must be closely observed to prevent possible minor personal injury.

- The safety information includes the "CAUTION" keyword in its heading with a general warning symbol.
- · The risk is explained using a symbol on the edge of the page.

Technical aspects which the user must observe to avoid material or equipment damage.

Instructions and lists detailing step-by-step actions for given situations can be recognised via bullet points, e.g.:

• Insert the welding current lead socket into the relevant socket and lock.



2.2 Explanation of icons

Symbol	Description	Symbol	Description
RF .	Indicates technical aspects which the user must observe.	\Leftrightarrow	Activate and release / Tap / Tip
	Switch off machine		Release
0	Switch on machine		Press and hold
(*)	Incorrect / Invalid		Switch
	Correct / Valid	O	Turn
	Input		Numerical value – adjustable
①	Navigation		Signal light lights up in green
	Output	••••	Signal light flashes green
45	Time representation (e.g.: wait 4 s / actuate)	-)-	Signal light lights up in red
-//-	Interruption in the menu display (other setting options possible)	•••••	Signal light flashes red
*	Tool not required/do not use	->	Signal light lights up in blue
	Tool required/use	•••••	Signal light flashes blue



2.3 Safety instructions



⚠ WARNING

Risk of accidents due to non-compliance with the safety instructions! Non-compliance with the safety instructions can be fatal!

- Carefully read the safety instructions in this manual!
- Observe the accident prevention regulations and any regional regulations!
- Inform persons in the working area that they must comply with the regulations!



Risk of injury from electrical voltage!

Voltages can cause potentially fatal electric shocks and burns on contact. Even low voltages can cause a shock and lead to accidents.

- Never touch live components such as welding current sockets or stick, tungsten or wire electrodes!
- Always place torches and electrode holders on an insulated surface!
- Wear the full personal protective equipment (depending on the application)!
- The machine may only be opened by qualified personnel!
- The device must not be used to defrost pipes!



Hazard when interconnecting multiple power sources!

If a number of power sources are to be connected in parallel or in series, only a technical specialist may interconnect the sources as per standard IEC 60974-9:2010: Installation and use and German Accident Prevention Regulation BVG D1 (formerly VBG 15) or country-specific regulations.

Before commencing arc welding, a test must verify that the equipment cannot exceed the maximum permitted open circuit voltage.

- Only qualified personnel may connect the machine.
- When taking individual power sources out of operation, all mains and welding current leads must be safely disconnected from the welding system as a whole. (Hazard due to reverse polarity voltage!)
- Do not interconnect welding machines with pole reversing switch (PWS series) or machines for AC welding since a minor error in operation can cause the welding voltages to be combined, which is not permitted.




Risk of injury due to radiation or heat!

Arc radiation can lead to skin and eye injuries.

Contact with hot workpieces and sparks can lead to burns.

- Use hand shield or welding helmet with the appropriate safety level (depends on the application).
- Wear dry protective clothing (e.g. hand shield, gloves, etc.) in accordance with the applicable regulations of your country.
- Persons who are not directly involved should be protected with a welding curtain or suitable safety screen against radiation and the risk of blinding!

099-008235-EW501 6 24.02.2023









Risk of injury due to improper clothing!

During arc welding, radiation, heat and voltage are sources of risk that cannot be avoided. The user has to be equipped with the complete personal protective equipment at all times. The protective equipment has to include:

- Respiratory protection against hazardous substances and mixtures (fumes and vapours);
 otherwise implement suitable measures such as extraction facilities.
- Welding helmet with proper protection against ionizing radiation (IR and UV radiation) and heat
- Dry welding clothing (shoes, gloves and body protection) to protect against warm environments with conditions comparable to ambient temperatures of 100 °C or higher and arcing and work on live components.
- Hearing protection against harming noise.



Explosion risk!

Apparently harmless substances in closed containers may generate excessive pressure when heated.

- Move containers with inflammable or explosive liquids away from the working area!
- Never heat explosive liquids, dusts or gases by welding or cutting!



Fire hazard!

Due to the high temperatures, sparks, glowing parts and hot slag that occur during welding, there is a risk of flames.

- · Be watchful of potential sources of fire in the working area!
- Do not carry any easily inflammable objects, e.g. matches or lighters.
- Ensure suitable fire extinguishers are available in the working area!
- Thoroughly remove any residue of flammable materials from the workpiece prior to starting to weld.
- Only further process workpieces after they have cooled down. Do not allow them to contact any flammable materials!



A CAUTION



Smoke and gases!

Smoke and gases may lead to shortness of breath and poisoning! The ultraviolet radiation of the arc may also convert solvent vapours (chlorinated hydrocarbon) into poisonous phosgene.

- · Ensure sufficient fresh air!
- · Keep solvent vapours away from the arc beam field!
- · Wear suitable respiratory protection if necessary!
- To prevent the formation of phosgene, residues of chlorinated solvents on workpieces must first be neutralised using appropriate measures.



Noise exposure!

Noise exceeding 70 dBA can cause permanent hearing damage!

- · Wear suitable ear protection!
- Persons located within the working area must wear suitable ear protection!









According to IEC 60974-10, welding machines are divided into two classes of electromagnetic compatibility (the EMC class can be found in the Technical data) > see 8 chapter:

Class A machines are not intended for use in residential areas where the power supply comes from the low-voltage public mains network. When ensuring the electromagnetic compatibility of class A machines, difficulties can arise in these areas due to interference not only in the supply lines but also in the form of radiated interference.

Class B machines fulfil the EMC requirements in industrial as well as residential areas, including residential areas connected to the low-voltage public mains network.

Setting up and operating

When operating arc welding systems, in some cases, electro-magnetic interference can occur although all of the welding machines comply with the emission limits specified in the standard. The user is responsible for any interference caused by welding.

In order to **evaluate** any possible problems with electromagnetic compatibility in the surrounding area, the user must consider the following: (see also EN 60974-10 Appendix A)

- Mains, control, signal and telecommunication lines
- · Radios and televisions
- Computers and other control systems
- Safety equipment
- The health of neighbouring persons, especially if they have a pacemaker or wear a hearing aid
- Calibration and measuring equipment
- · The immunity to interference of other equipment in the surrounding area
- · The time of day at which the welding work must be carried out


Recommendations for reducing interference emission

- · Mains connection, e.g. additional mains filter or shielding with a metal tube
- Maintenance of the arc welding system
- · Welding leads should be as short as possible and run closely together along the ground
- Potential equalization
- Earthing of the workpiece. In cases where it is not possible to earth the workpiece directly, it should be connected by means of suitable capacitors.
- · Shielding from other equipment in the surrounding area or the entire welding system



Electromagnetic fields!

The power source can create electrical or electromagnetic fields that may impair the function of electronic systems such as EDP and CNC devices, telecommunication, power and signal lines as well as pacemakers and defibrillators.



- Shield radiation-sensitive equipment or facilities appropriately!
- The function of pacemakers may be impaired (seek medical advice if necessary).

8 099-008235-EW501



▲ CAUTION



Obligations of the operator!

The respective national directives and laws must be complied with when operating the machine!

- Implementation of national legislation relating to framework directive 89/391/EEC on the introduction of measures to encourage improvements in the safety and health of workers at work and associated individual guidelines.
- In particular, directive 89/655/EEC concerning the minimum safety and health requirements for the use of work equipment by workers at work.
- The regulations applicable to occupational safety and accident prevention in the country concerned.
- Setting up and operating the machine as per IEC 60974.-9.
- Brief the user on safety-conscious work practices on a regular basis.
- Regularly inspect the machine as per IEC 60974.-4.



The manufacturer's warranty becomes void if non-genuine parts are used!

- Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!
- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.

Requirements for connection to the public mains network

High-performance machines can influence the mains quality by taking current from the mains network. For some types of machines, connection restrictions or requirements relating to the maximum possible line impedance or the necessary minimum supply capacity at the interface with the public network (Point of Common Coupling, PCC) can therefore apply. In this respect, attention is also drawn to the machines' technical data. In this case, it is the responsibility of the operator, where necessary in consultation with the mains network operator, to ensure that the machine can be connected.

2.4 Transport and installation



⚠ WARNING

Risk of injury due to improper handling of shielding gas cylinders! Improper handling and insufficient securing of shielding gas cylinders can cause serious injuries!

- Observe the instructions from the gas manufacturer and any relevant regulations concerning the use of compressed air!
- Do not attach any element to the shielding gas cylinder valve!
- Prevent the shielding gas cylinder from heating up.



A CAUTION



Risk of accidents due to supply lines!

During transport, attached supply lines (mains leads, control cables, etc.) can cause risks, e.g. by causing connected machines to tip over and injure persons!

Disconnect all supply lines before transport!



Risk of tipping!

There is a risk of the machine tipping over and injuring persons or being damaged itself during movement and set up. Tilt resistance is guaranteed up to an angle of 10° (according to IEC 60974-1).

- Set up and transport the machine on level, solid ground.
- Secure add-on parts using suitable equipment.



Risk of accidents due to incorrectly installed leads!

Incorrectly installed leads (mains, control and welding leads or intermediate hose packages) can present a tripping hazard.

- Lay the supply lines flat on the floor (avoid loops).
- Avoid laying the leads on passage ways.



Risk of injury from heated coolant and its connections!

The coolant used and its connection or connection points can heat up significantly during operation (water-cooled version). When opening the coolant circuit, escaping coolant may cause scalding.

- · Open the coolant circuit only when the power source or cooling unit is switched off!
- · Wear proper protective equipment (protective gloves)!
- · Seal open connections of the hose leads with suitable plugs.
- B

The units are designed for operation in an upright position!

Operation in non-permissible positions can cause equipment damage.

• Only transport and operate in an upright position!



Accessory components and the power source itself can be damaged by incorrect connection!

- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.
- Comprehensive descriptions can be found in the operating instructions for the relevant accessory components.
- Accessory components are detected automatically after the power source is switched on.

Ŕ

Protective dust caps protect the connection sockets and therefore the machine against dirt and damage.

- The protective dust cap must be fitted if there is no accessory component being operated on that connection.
- The cap must be replaced if faulty or if lost!



3 Intended use

▲ WARNING



Hazards due to improper usage!

The machine has been constructed to the state of the art and any regulations and standards applicable for use in industry and trade. It may only be used for the welding procedures indicated at the rating plate. Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!

- The equipment must only be used in line with its designated purpose and by trained or expert personnel!
- Do not improperly modify or convert the equipment!

3.1 **Applications**

These cooling modules are designed solely for cooling welding torches.

We can only guarantee smooth and trouble-free operation when used in conjunction with the welding machines, welding torches, coolants and accessory components from our range.

3.1.1 For operation only with the following equipment

Tetrix 300 Smart/Classic/Comfort

3.1.2 Warranty

For more information refer to the "Warranty registration" brochure supplied and our information regarding warranty, maintenance and testing at www.ewm-group.com!

3.1.3 **Declaration of Conformity**



This product corresponds in its design and construction to the EU directives listed in the declaration. The product comes with a relevant declaration of conformity in the original.

The manufacturer recommends carrying out the safety inspection according to national and international standards and guidelines every 12 months (from commissioning).

3.1.4 Service documents (spare parts and circuit diagrams)



WARNING



No improper repairs and modifications!

To prevent injuries and damage to the machine, only competent personnel (authorised service personnel) are allowed to repair or modify the machine.

Unauthorised manipulations will invalidate the warranty!

Instruct competent personnel (authorised service personnel) to repair the machine.

Original copies of the circuit diagrams are enclosed with the unit.

Spare parts can be obtained from the relevant authorised dealer.



3.1.5 Part of the complete documentation

This document is part of the complete documentation and valid only in combination with all other parts of these instructions! Read and observe the operating instructions for all system components, especially the safety instructions!

The illustration shows a general example of a welding system.





Figure 3-1

Item	Documentation
A.1	Transport vehicle
A.2	Power source
A.3	Cooling unit
A.4	Welding torch
A.5	Remote control
A.6	Control
Α	Complete documentation



Machine description - quick overview 4

4.1 Front view / rear view



Machine description – quick overview Front view / rear view





Item	Symbol	Description
1		Tension bracket closure
		Connection between the cooling unit and the welding machine
2	4	Quick connect coupling, red
	Red	Coolant return from the welding torch
3	\hookrightarrow	Quick connect coupling, blue
	Blue	Coolant supply to the welding torch
4		Cooling air inlet
5		Machine feet
6		Connector plug, 4-pole
		Cooling unit voltage supply
7		Connector plug, 8-pole
		Cooling unit control lead
8		Cooling air outlet
9		Coolant drain hose
		Device for draining the coolant
10	0/2	Automatic cut-out of coolant pump key button
	0/3	press to reset a triggered fuse
11		Coolant tank > see 5.5 chapter
12		Coolant tank cap



5 Design and function

\triangle

WARNING



Risk of injury from electrical voltage! Contact with live parts, e.g. power connections, can be fatal!

- · Observe the safety information on the first pages of the operating instructions!
- Commissioning must be carried out by persons who are specifically trained in handling power sources!
- · Connect connection or power cables while the machine is switched off!

Read and observe the documentation to all system and accessory components!


5.1 Assembly



⚠ WARNING

Risk of accidents due to unlocked tension closures! When mounting a power source with cooling unit, ensure a clean environment and proper installation. In case of incorrect installation, the cooling unit can come loose and cause severe injuries.

- Remove any dirt from the power source machine feet and the cooling unit tension closures before installation.
- Before transportation, check the closure is securely locked (completely rotate the tension closures clockwise and snap in)!



Assembly and disassembly is very simple and doesn't require any tools.




Figure 5-1

Item	Symbol	Description
1		Locking hook
2		Butterfly handle

 Lift the wing-tip handles on the tension bracket closure (A2) and turn anti-clockwise (B2) until the locking hook is extended.






Figure 5-2

Position the welding machine on the module as shown in fig.




Figure 5-3

- Turn the wing-tip handle clockwise (B2) to close the fastening.
- Engage the locking hook in the recesses in the side walls of the welding machine.




Figure 5-4

Lay the wing-tip handle down flat (C2).



5.2 Removal

- Lift the wing-tip handle and turn anti-clockwise until the locking hook is extended.
- · Lift the locking hook out of the recesses on the welding machine.
- · The welding machine can be lifted off the cooling unit.

5.3 Connecting the supply lines

Control and supply lead to the welding machine

The cooling module and welding machine are connected using two leads.

- Insert the control lead plug on the welding machine.
- Insert the power supply lead plug on the welding machine.



5.4 Transport and installation

MARNING



Risk of accident due to improper transport of machines that must not be lifted! Do not lift or suspend the machine! The machine can drop and cause injuries! The handles, straps or brackets are suitable for transport by hand only!

• The machine must not be suspended or lifted using a crane.

5.4.1 Machine cooling



Insufficient ventilation results in a reduction in performance and equipment damage.

- · Observe the ambient conditions!
- Keep the cooling air inlet and outlet clear!
- Observe the minimum distance of 0.5 m from obstacles!

5.4.2 Ambient conditions



The machine must not be operated in the open air and must only be set up and operated on a suitable, stable and level base!

- The operator must ensure that the ground is non-slip and level, and provide sufficient lighting for the place of work.
- Safe operation of the machine must be guaranteed at all times.



Equipment damage due to contamination!

Unusually high amounts of dust, acids, corrosive gases or substances can damage the machine (observe maintenance intervals > see 6.3 chapter).

Avoid large amounts of smoke, steam, oily fumes, grinding dust and corrosive ambient air!

In operation

Temperature range of the ambient air:

-25 °C to +40 °C (-13 °F to 104 °F) [1]

Relative humidity:

- up to 50 % at 40 °C (104 °F)
- up to 90 % at 20 °C (68 °F)

Transport and storage

Storage in a closed room, temperature range of the ambient air:

-30 °C to +70 °C (-22 °F to 158 °F) [1]

Relative humidity

- up to 90 % at 20 °C (68 °F)
- [1] Ambient temperature dependent on coolant! Observe the coolant temperature range of the torch cooling

5.5 Welding torch cooling system



Material damage due to unsuitable coolants!

Unsuitable coolant, coolants mixed with other types / liquids or use in an unsuitable temperature range will result in material damage and loss of the manufacturer's warranty!

- Operation without coolant is not permitted! Dry running will destroy the cooling components such as the coolant pump, welding torch and hose packages.
- Only use the coolants described in these instructions for the specified ambient conditions (temperature range) > see 5.5.2 chapter.
- Do not mix coolants of different types (including those described in these instructions).
- When changing the coolant, all liquid must be replaced and the cooling system flushed.

Dispose of the coolant in accordance with local regulations and the material safety data sheets.

099-008235-EW501 24.02.2023



5.5.1 **Functional characteristics**

The cooling modules (pump and fan) are controlled by the welding machine only.

The welding machine automatically detects and displays a lack of coolant (see the welding machine operating instructions).

5.5.2 Permitted torch coolant

Coolant	Temperature range
blueCool -10	-10 °C to +40 °C (14 °F to +104 °F)
KF 23E (Standard)	-10 °C to +40 °C (14 °F to +104 °F)
KF 37E	-20 °C to +30 °C (-4 °F to +86 °F)
blueCool -30	-30 °C to +40 °C (-22 °F to +104 °F)

5.5.3 Maximal hose package length

All information relates to the total hose package length of the complete welding system and presents exemplary configurations (of components of the EWM product portfolio with standard lengths). A straight kink-free installation is to be ensured, taking into account the max. delivery height.

Pump: Pmax = 3.5 bar (0.35 MPa)

Power source	Hose package	Wire feeder	miniDrive	Welding torch	max.
	※	*	⊘	⊗	
Compost			(25 m / 82 ft.)	(5 m / 16 ft.)	
Compact	⊘	⊗	(X)	⊗ ⊗	
	(20 m / 65 ft.)			(5 m / 16 ft.)	30 m
	⊗	⊗	(X)	⊗	98 ft.
Docompost	(25 m / 82 ft.)			(5 m / 16 ft.)	
Decompact	⊘	⊘	⊘	⊘	
	(15 m / 49 ft.)		(10 m / 32 ft.)	(5 m / 16 ft.)	


5.5.4 Adding coolant



If the cooling system is empty or only insufficiently filled with coolant, the coolant pump is automatically switched off after approx. one minute (protection against destruction). At the same time, the welding data display signals the lack of coolant or low coolant level.

Reset the coolant error, fill coolant and repeat the operation.

The unit is supplied ex works with a minimum level of coolant.




Item	Symbol	Description
1		Coolant tank cap



Item	Symbol	Description	
2		Coolant filter sieve	
3		Coolant tank > see 5.5 chapter	
4		"Min" mark	
		Minimum coolant level	

- · Unscrew and remove the coolant tank sealing cover.
- Check filter sieve insert for dirt, clean if necessary and reinsert into position.
- Top up coolant to the filter sieve insert, close sealing cover again.



If there is less coolant in the coolant tank than the minimum required you may need to vent the coolant circuit. In this case the welding machine will automatically shut down the coolant pump and signal an error, > see 7.2 chapter.

5.6 Welding torch connection



The cooling circuit (cooling unit <> welding torch) must not be interrupted. Otherwise, the coolant pump can be destroyed by thermal overload (the coolant cannot circulate). When using aircooled welding torches, one of the following measures must be taken depending on the machine version:

- Switch off the torch cooling (see function "Torch cooling mode" in the machine configuration menu of the control description).
- Insert a hose bridge between the coolant flow and return (the coolant can circulate in the cooling unit).
- Disconnect the control and supply line between the cooling unit and the welding machine.
- Lock connecting nipples of the cooling water tubes into the corresponding quick connect couplings: Return line red to quick connect coupling, red (coolant return) and supply line blue to quick connect coupling, blue (coolant supply).

099-008235-EW501 24.02.2023



6 Maintenance, care and disposal

6.1 General

M DANGER



Risk of injury due to electrical voltage after switching off!

Working on an open machine can lead to fatal injuries!

Capacitors are loaded with electrical voltage during operation. Voltage remains present for up to four minutes after the mains plug is removed.

- 1. Switch off machine.
- 2. Remove the mains plug.
- 3. Wait for at last 4 minutes until the capacitors have discharged!

MARNING



Improper maintenance, testing and repairs!

Maintenance, testing and repair of the machine may only be carried out by skilled and qualified personnel (authorised service personnel). A competent person is someone who, based on training, knowledge and experience, can recognize the hazards and possible consequential damage that may occur when testing power sources and can take the necessary safety precautions.

- Follow the maintenance instructions > see 6.3 chapter.
- If any of the test requirements below are not met, the unit must not be put back into operation until it has been repaired and tested again.

Repair and maintenance work may only be performed by qualified authorised personnel; otherwise the right to claim under warranty is void. In all service matters, always consult the dealer who supplied the machine. Return deliveries of defective equipment subject to warranty may only be made through your dealer. When replacing parts, use only original spare parts. When ordering spare parts, please quote the machine type, serial number and item number of the machine, as well as the type designation and item number of the spare part.

Under the specified ambient conditions and normal working conditions this machine is essentially maintenance-free and requires just a minimum of care.

Contamination of the machine may impair service life and duty cycle. The cleaning intervals depend on the ambient conditions and the resulting contamination of the machine. The minimum interval is every six months.

6.2 Cleaning

- · Clean the outer surfaces with a moist cloth (no aggressive cleaning agents).
- Purge the machine venting channel and cooling fins (if present) with oil- and water-free compressed air. Compressed air may overspeed and destroy the machine fans. Never direct the compressed air directly at the machine fans. Mechanically block the fans, if required.
- Check the coolant for contaminants and replace, if necessary.

6.2.1 Dirt filter

When using a dirt filter, the cooling air throughput is reduced and the duty cycle of the machine is reduced as a result. The duty cycle decreases with the increasing contamination of the filter. The dirt filter must be remove at regular intervals and cleaned by blowing out with compressed air (depending on the level of soiling).



6.3 Maintenance work, intervals

6.3.1 Daily maintenance tasks

Visual inspection

- · Mains supply lead and its strain relief
- · Gas cylinder securing elements
- Check hose package and power connections for exterior damage and replace or have repaired by specialist staff as necessary!
- · Gas tubes and their switching equipment (solenoid valve)
- Check that all connections and wearing parts are hand-tight and tighten if necessary.
- Check correct mounting of the wire spool.
- · Wheels and their securing elements
- Transport elements (strap, lifting lugs, handle)
- · Other, general condition

Functional test

- · Operating, message, safety and adjustment devices (Functional test)
- Welding current cables (check that they are fitted correctly and secured)
- Gas tubes and their switching equipment (solenoid valve)
- · Gas cylinder securing elements
- · Check correct mounting of the wire spool.
- Check that all screw and plug connections and replaceable parts are secured correctly, tighten if necessary.
- · Remove any spatter.
- Clean the wire feed rollers on a regular basis (depending on the degree of soiling).

6.3.2 Monthly maintenance tasks

Visual inspection

- · Casing damage (front, rear and side walls)
- · Wheels and their securing elements
- Transport elements (strap, lifting lugs, handle)
- Check coolant tubes and their connections for impurities

Functional test


- Selector switches, command devices, emergency stop devices, voltage reducing devices, message and control lamps
- Check wire guide elements (wire feed roll holder, wire feed nipple, wire guide tube) for tight fit. Recommendation for replacing the wire feed roll holder (eFeed) after 2000 hours of operation, see replacement parts).
- · Check coolant tubes and their connections for impurities
- Check and clean the welding torch. Deposits in the torch can cause short circuits and have a negative impact on the welding result, ultimately causing damage to the torch.

6.3.3 Annual test (inspection and testing during operation)

A periodic test according to IEC 60974-4 "Periodic inspection and test" has to be carried out. In addition to the regulations on testing given here, the relevant local laws and regulations must also be observed. For more information refer to the "Warranty registration" brochure supplied and our information regarding warranty, maintenance and testing at www.ewm-group.com!

22 099-008235-EW501 24.02.2033

Maintenance, care and disposal





6.4 Disposing of equipment



Proper disposal!

The machine contains valuable raw materials, which should be recycled, and electronic components, which must be disposed of.

- · Do not dispose of in household waste!
- Observe the local regulations regarding disposal!
- According to European provisions (Directive 2012/19/EU on Waste of Electrical and Electronic
 Equipment), used electric and electronic equipment may no longer be placed in unsorted municipal
 waste. It must be collected separately. The symbol depicting a waste container on wheels indicates
 that the equipment must be collected separately.

This machine has to be disposed of, or recycled, in accordance with the waste separation systems in use.

According to German law (law governing the distribution, taking back and environmentally correct disposal of electrical and electronic equipment (ElektroG)), used machines are to be placed in a collection system separate from unsorted municipal waste. The public waste management utilities (communities) have created collection points at which used equipment from private households can be disposed of free of charge.

The deletion of personal data is the responsibility of the end user.

Lamps, batteries or accumulators must be removed and disposed of separately before disposing of the device. The type of battery or accumulator and its composition is marked on the top (type CR2032 or SR44). The following EWM products may contain batteries or accumulators:

- Welding helmets
 Batteries or accumulators are easy to remove from the LED cassette.
- Device controls
 Batteries or accumulators are located on the back of these in corresponding sockets on the circuit board and are easy to remove. The controls can be removed using standard tools.

Information on returning used equipment or collections can be obtained from the respective municipal administration office. Devices can also be returned to EWM sales partners across Europe.

Further information on the topic of the disposal of electrical and electronic equipment can be found on our website at: https://www.ewm-group.com/de/nachhaltigkeit.html.

099-008235-EW501 24.02.2023



7 Rectifying faults

All products are subject to rigorous production checks and final checks. If, despite this, something fails to work at any time, please check the product using the following flowchart. If none of the fault rectification procedures described leads to the correct functioning of the product, please inform your authorised dealer

7.1 Checklist for rectifying faults

The correct machine equipment for the material and process gas in use is a fundamental requirement for perfect operation!

Please observe the welding machine operating instructions.

Legend	Symbol	Description
	*	Fault/Cause
	*	Remedy


Coolant error/no coolant flowing


- ✓ Insufficient coolant flow
 - Check coolant level and refill if necessary
 - ★ Eliminate kinks in conduit system (hose packages)
 - ★ Extend and lay out the torch hose package
 - Reset automatic cutout of the coolant pump by activating
- ★ Air in the coolant circuit
 - ★ Vent coolant circuit > see 7.2 chapter
- ✓ Coolant pump blocked
 - Switch on pump shaft (specialist staff only) > see 7.3 chapter


Functional errors

- ✓ Connection problems
 - * Make control lead connections and check that they are fitted correctly.

7.2 Vent coolant circuit











Figure 7-1

- Switch off the machine and fill the coolant tank to the maximum level.
- Unlock the quick-connect coupling with a suitable tool (connection open).

To vent the cooling system always use the blue coolant connection, which is located as deep as possible inside the system (close to the coolant tank)!








Figure 7-2

- Position a suitable collection container for collecting the escaping coolant at the quick-connect coupling and switch on the machine for approx. 5s.
- · Lock the quick-connect coupling by pushing back the locking ring.

7.3 Fixing the pump shaft (coolant circuit)



▲ WARNING

Danger – electrical voltage!

To carry out this measure, the unit has to be opened. To avoid injuries and damage to the unit, the unit may only be repaired by qualified and skilled persons!

· Assign repairs to qualified service technicians!

Continuing non-use and impurities in the coolant may result in the the coolant pump not being in proper working order.



8 Technical data

The limit value determination of technical data results from considering the combined overall system (cooling unit and welding machine).

8.1 cool 35 U31

Supply voltage (from the welding machine)	1x 400 V
Frequency	50/60 Hz
Cooling capacity at 1 l/min (+25°C/77°F)	800 W
Ambient temperature [1]	-25 °C to +40 °C
max. Flow rate	5 l/min / 1,3 gal./min
max. Delivery height	35 m / 115 ft.
max. Pump pressure	3,5 bar / 0.35 MPa
Pump	Centrifugal pump
max. Tank content	5 I / 1.3gal.
Protection class	I
Overvoltage category	III
Contamination level	3
Coolant	> see 5.5.2 chapter
Machine cooling / protection classification	Fan (AF) / IP 23 [3]
Noise level [2]	< 70 dB(A)
EMC class	A
Test mark	C € / EMI / ŁK
Standards used	See declaration of conformity (appliance documents)
Dimensions (I x b x h)	593 x 244 x 224 mm 23.3 x 9.6 x 8.8 inch
Weight without coolant	15 kg 33.1 lb.

^[1] Ambient temperature dependent on coolant! Observe coolant temperature range!

Noise level during idle mode and operation under standard load according to IEC 60974-1 at the maximum operating point.

^[3] Mounted state



9 Accessories

9.1 Welding torch cooling system

Туре	Designation	Item no.
HOSE BRIDGE UNI	Tube bridge	092-007843-00000

9.1.1 Coolant - type blueCool

Туре	Designation	Item no.
blueCool -10 5 I	Coolant up to -10 °C (14 °F), 5 I	094-024141-00005
blueCool -10 25 l	Coolant up to -10 °C (14 °F), 25 I	094-024141-00025
blueCool -30 5 I	Coolant up to -30 °C (22 °F), 5 I	094-024142-00005
blueCool -30 25 l	Coolant up to -30 °C (22 °F), 25 I	094-024142-00025
FSP blueCool	Frost protection tester	094-026477-00000

9.1.2 Coolant - type KF

Туре	Designation	Item no.
KF 23E-5	Coolant up to -10 °C (14 °F), 5 I	094-000530-00005
KF 23E-200	Coolant (-10 °C), 200 litres	094-000530-00001
KF 37E-5	Coolant up to -20 °C (4 °F), 5 I	094-006256-00005
KF 37E-200	Coolant (-20 °C), 200 I	094-006256-00001
TYP1	Frost protection tester	094-014499-00000



Appendix 10

10.1 Searching for a dealer

Sales & service partners www.ewm-group.com/en/specialist-dealers



"More than 400 EWM sales partners worldwide"